


# Quick Start Guide

This guide explains how to present audio and video content



Presentation




# 1 Turn on System

LAKE SIDE PAVILION


## 1 Enter password

- Touching the screen will bring you to the password page
- Enter the password **0307** and select **Enter** to proceed




## 2 Select an activity

- Select one of two activities:
  1. **Video Presentation** to turn on system and send content to the projector. See [page 3](#) for help.
  2. **Audio Presentation** to turn on the system and send audio content to the speakers



## Navigating the control panel

- Use the buttons on the side of the control panel to make changes at any time:
  1. Press here to turn off the system
  2. Press the Home button to return to the main page at anytime
  3. Adjust the room volume using the two arrows





# 2 Present Content


LAKESIDE PAVILION

## 1 Connect laptop to inputs

- To show content from your laptop on the projector, you must connect to the room inputs
- Connect using either an HDMI or a VGA cable then proceed to **Step 2**



Note that the VGA cable (seen to the left) does not carry audio, so an audio jack (below) must be plugged into the headphone port on your laptop.




When connecting an HDMI cable to your laptop, be sure the tip matches the orientation of the port as seen here.




## 2 Turn on projector

- Select **Projector Control**
- Turn on projector
- Lower screen




You can also simply select an input source and the system will automatically turn on the projector and lower the screen





## 3 Select a presentation source

- Select an input source you want to view on the projector
- Use arrows on touch panel to adjust overall presentation volume



## 4 Turn off system

- Push the power button 
- Select **Yes, Turn The System Off** or **No, Return Me To The Main Page**



QSC  
DIRECT 70W AMPLIFIER  
CX204V

CH1 CLIP 2 POWER 3 CLIP CH4  
-20dB 187 184 -20dB  
-20dB 187 184 -20dB  
510 PAR 510



